

COIL WINDING MACHINE ERN G-VERSION

USER'S GUIDE

Version: 3.3

Issue Date : 19.04.2016



ERN 100, 150, 200



TPC s.r.o.
Pálenica 53/79
033 01 Liptovský Hrádok
SLOVAKIA
Tel.: +421-44-5221633
Fax: +421-44-5222088
E-mail: tpc@tpc.sk
www.tpc.sk

1. Introduction	1
1.1 Characteristic features	1
2. Technical data	2
2.1 Climatic conditions	2
3. Description of machine	2
3.1 Description of controls	3
4. Installation and preparation of working equipment	6
4.1 Mechanical installation	6
4.2 Power connection	6
4.3 UPS	7
4.4 Machine preparation for running	7
5. Winding operation	8
5.1 Machine switching ON and gear setting	8
5.2 Winding data back up while electricity drop	9
5.3 Winding and view window	10
5.4 Explanation of conceptions STANDSTILL, START, STOP	10
5.5 Winding program selection	11
5.6 Start and Stop of winding cycle	12
5.7 Foot pedal	12
5.9 Winding corrections	14
5.9.1 Spindle reference position setting	14
5.9.2 Wire guide relative position setting	14
5.9.3 Number of turns correction	15
5.9.4 Total counter	16
5.9.5 Wire guide correction	17
5.9.6 Wire guide direction change	17
5.9.7 Step abort	18
5.9.8 Back winding	18
5.9.9 Deceleration ramp for the STOP - button	19
6. Programming	20
6.1 Basis of programming	21
6.2 Step choice	21
6.3 Step parameters programming	22
6.3.1 Basic step types	22
6.3.2 Choice of step type	22
6.3.3 Winding step	23
6.3.4 Wire guide shift	28
6.3.5 Wire guide jump	30
6.3.6 Pause	31
6.4 Display and assignment of the layer	33
6.5 Programming corrections	34
6.5.1 Empty step insert	34
6.5.2 Step cancel	35
6.5.3 Step copy	36
6.5.4 Global change	37
6.5.5 Coordinate offset	38
6.6 Special functions	39
6.6.1 Layer-stop	39
6.6.2 Automatic correction	40
6.6.3 Automatic switch to manual regime	42
6.6.4 Trapezoidal winding	43

6.7 Auxiliary inputs and outputs	45
6.7.1 View window for inputs and outputs	45
6.7.2 Digital inputs programming	46
6.7.3 Digital outputs programming	47
6.8 Program name	49
7. Program saving and opening	50
7.1 Program opening	51
7.2 Program saving	52
8. Menu	54
8.1 Program locking	56
8.2 USB flash drive	56
8.3 Machine model choice	56
8.4 Display language	57
8.5 Joystick action	57
8.6 Program (block) delete	58
8.7 Access PIN code setting	58
8.8 Error messages	59
8.9 Winder number	60
8.10 Accept file name	60
9. ERROR report	61
10. USB host port	62
10.1 Display help	64
10.2 Tree type structure	64
10.3 Load from flash drive	65
10.4 Save actual program to flash drive	67
10.5 Create a new directory	69
10.6 Delete file or directory	70
10.7 Rename file or directory	70
10.8 Save marked programs to flash drive	71
10.9 Save programs 1 - 80 (81 - 160) to flash drive	73
10.10 Load from flash drive	74
10.11 Firmware Upgrades	75
11. Gear change	79
11.1 Gear change ERN 100	79
11.2 Gear change ERN 150	79
11.3 Gear change ERN 200	79
11.4 Gear change ERN 500	79
12. Serial interface RS 232	81
13. Package contents	81
14. Fuse change	81
15. Maintenance	81
16. Warranty period and service	81
17. Appendices	

1. INTRODUCTION

Universal coil winding machines ERN 100, 150, 200 are designed for winding heavy coils, transformers, chokes, resistors and especially for distribution transformes.

1.1 Characteristic features:

- wide range of application for winding simple or complicated coils, multichamber coils, trapezoidal or asymmetric windings
- AC servo, that is used like a spindle drive, assures excellent dynamical parameters, constant torque and accurate positioning
- wire guide on ball bearings with a separate AC servo motor
- accurate reversible turn counting
- microprocessor-controlled winding cycle without time waste
- wide programming options
- memory for 160 complicated coils (up to 350 steps)
- viewable and easy reading graphical display
- special functions LAYER-STOP, AUTOMATIC CORRECTION, MANUAL REGIME
- 4 programmable digital outputs
- 4 programmable digital inputs
- communication with PC by optically isolated interface RS-232 and USB host port
- UPS for back-up of power

2. TECHNICAL DATA

ERN 100

ERN 150

ERN 200

Pitch range (mm/rev):	0,000 - 160	0,000 - 160	0,000 - 160
Winding width (mm):	400 - 800 - 1200	400-800-1200	400-800-1200
Winding speed / torque (rpm/Nm):	600 / 75 300 / 150	300 / 150 150 / 300	150 / 270 75 / 540
Accuracy of spindle stop (rev):	0,01	0,01	0,01
Spindle position pre-set (rev):	0,01	0,01	0,01
Max.speed of wire guide - shift (mm/s)	100	100	100
- winding	75	75	75
Acceleration/deceleration:	table	table	table
Max.coil diameter (mm):	600 - 800	600 - 800	600 - 800
Distance between centres (mm):	800 ; 1200 ; 1600	800 ; 1200 ; 1600	800 ; 1200 ; 1600
Dimensions (mm):	1800x740 ; 2300x740; 2800x740	1800x740 ; 2300x740; 2800x740	1800x740 ; 2300x740; 2800x740
Weight (kg):	600 ; 750 ; 900	650 ; 800 ; 950	700 ; 850 ; 1000
Power supply (V/Hz):	3 x 400 / 50-60	3 x 400 / 50-60	3 x 400 / 50-60
Power consumption (kVA):	max. 7	max. 7	max. 7
Noise (dB):	74	74	74

2.1. Climatic conditions


Machine is designed for normal workshop's conditions with relative air moisture 70% and temperature in the range +15 up to +30°C.

3. DESCRIPTION OF MACHINE

Coil winding machine ERN consists of the following parts:



- controller containing control electronics and programming elements
- drive unit containing servomotor with gears, pitch control unit with separate servo motor, power electronics and control elements
- UPS unit containing UPS for power back-up, transformer and power supply
- base frame
- tailstock
- wire guide adjustable
- foot pedal
- support with spool holders and dereelers (optional accessories)

Winding cycle (linear acceleration, max.speed, linear deceleration and stop) is running automatically after the pressing the START-button. Deceleration is controlled by microprocessor to ensure accurate stopping and spindle positioning.





3.1 DESCRIPTION OF CONTROLS

- 1 - STAND BY switch
- 2 - EMERGENCY STOP - disconnects power in emergency
- 3 - POWER ON indicator
- 4 - START button - starts winding cycle
- 5 - STOP button - interrupts winding cycle
- 6 - Four-way JOYSTICK
- 7 - DISPLAY
- 8 - ENTER button - enters data to the memory
- 9 - PLUS and MINUS buttons - parameters correction and step choice
- 10 - RESET - sets the initial state
- 11 - Numeric buttons - enter the notes also
- 12 - Multifunction buttons - display served options choice
- 13 - Function buttons
- 14 - Connector for serial interface RS 232
- 15 - Gear cover with timing belt
- 16 - Connector for foot pedal
- 17 - Fixing screws
- 18 - Connector for inputs ,outputs and joystick
- 19 - STAND BY switch - disconnects the main power to the driver
- 20 - MANUAL button - allows manually winding by pedal
- 21 - UPS
- 22 - USB host port



ERN 100, 150, 200



4. INSTALLATION AND PREPARATION OF WORKING EQUIPMENT

4.1 Mechanical installation


The winding machine is fixed to the transport wooden pallet. It is necessary to prepare a level balanced surface for its final location. The both frame surfaces must be balanced horizontal in one surface. The winding machine is moved by lifting at 3 pendant eyes. At the winding of heavy coils there is recommend to fix the base frame with screws M 12 directly to flooring surface.

4.2 Power connection


The machine must be connected to four- or five-wire system of the supply voltage 3N/PE400V/230V,50 Hz TN-S with tolerance $\pm 5\%$ and max. power consumption 7 kVA. Before plug in the connection cable make sure that electric power accordance with technical requirements. Only professional staff who are qualified in electrical engineering are allowed to install the power connection to the machine.

There is no guarantee for damages caused by wrong or out of range connection to the power supply.

Four-wire system - recommended connecting



Five-wire system - recommended connecting



An additional switch "V" is recommended to use in case, if the lead-in cable is fixly connected to the line distribution. If the moving terminal is used for the installation, this switch will be not necessary.

4.3 UPS

The UPS is alive constantly, if the main switch (19) is in off-position, as well. In common running the UPS must be switched on constantly. In case of continual fall-out loss of the line voltage, e.g. electric distribution breakdown, repairs and re-designs or when the running is dead, it is necessary to set the UPS to off, that the useless discharge of storage batteries does not arise. For this purpose we remove the supply cover (21) and press the off button with a suitable tool (e.g. a pen). Repeated switch on is made by pressing the on button.

The winding machine is switched over to the stand-by position by setting the switch (1) to off. After few second the display shows POWER OFF. Actual winding data is recorded in the EEPROM. We return to the initial regime by repeated switching on the switch (1) and can continue winding.

If the electric power supply was broken in the whole system - e.g. by setting the switch EMERGENCY STOP (2) to off, by the main switch (19) or the length of fall-out loss of the line voltage surpassed the battery capacity of the UPS (more than 90 minutes), the hard RESET will arise after renewing electric power supply. After pressing the ENTER button the last remembered data from EEPROM will be set up.

If the electric power supply is broken while winding, the spindle will stop and the winding machine switch over to the stand-by after few second. After renewing electric power supply the machine returns to the initial regime, but in the position like after pressing the STOP button.

Keep always the following order at switching off and on the winding machine:

SWITCH ON: a) the UPS - if it was off
b) the main switch or EMERGENCY STOP (2)
c) the stand-by switch (1)

SWITCH OFF: a) the stand-by switch (1), wait till the display shows POWER OFF
b) the main switch (19)
c) the UPS only if it is necessary

4.4 Machine preparation for running

The machine operating is allowed only by skilled person who is acquainted with user's guide and safety formulas. The training is provided by producer or qualified person.

The machine is delivered partly disassembled for easier packing and transport. Before you switch the machine on, for the first time, assemble it as follows:

- a) Mount the controller on the drive unit. Connect the power plug, 25-pin connector and 9-pin CAN connector on the back panel of the controller
- b) Check and fasten the fuse cartridges on the back panel of the drive unit
- c) Connect the foot pedal to the connector (16)
- d) The UPS cover (21) is removed and the UPS is switched on by pressing the button

Assembly is completed by this and prepared to work.


5. WINDING OPERATION

5.1 Machine switching ON and gear setting

After switching ON (1) the introduction window shows,




which provides informations about, for what type of machine is controller set. In this window we can change the set gear, which must be in ABSOLUTE ACCORDANCE with the set of mechanical gear.



After pressing ENTER-button, the initial set is done, which means, that wire guide is shifted left home (zero position), zero number of turns, zero step and the last program is set.

5.2 Winding data back up while electricity drop

In this window, we can activate the initial setting of the machine (wire guide position, number of turns and step) for the back up values.




After the activation of this function (MEM.POS.ON) the initial setting will be actualized for the values, memorized while electricity drop.

FOR USING THIS FUNCTION, THE MACHINE MUST BE EQUIPPED WITH THE UNINTERRUPTIBLE POWER SUPPLY UNIT (UPS) AND THE REPORT OF ELECTRICITY DROP (relay for POWER) MUST BE INSTALLED. IF THE MACHINE IS NOT EQUIPPED BY THIS, THE ACTIVATION OF THIS FUNCTION DOES NOT INFLUENCE THE INITIAL SETTING, WHICH IS STILL SET ON ZERO VALUES.


5.3 Winding and view window

These are two basic windows, in which we can start programmed cycle. Repeated pressing of the ENTER-button caused the switching.

Winding window - provides actual information about winding process



View window - displays the view of programmed step parameters



Winding is possible only in these two windows. If any other window is opened, the cycle start is blocked.

5.4 Explanation of conceptions STANDSTILL, START, STOP


STANDSTILL: State after switching ON the machine and pressing ENTER, or after the step finishing. Start from this state shifts program one step forward, generally. E.g. when we are in the step 0, after starting, the step 1 is running.

START: Active run of some step type (winding, shift, jump and pause).

STOP: State after pressing the STOP-button (cycle interruption). Repeated start activates interrupted run and there is no step shifting.

5.5 Winding program selection

Winding program, we are just working with(we can perform winding or program creation) is called **ACTUAL PROGRAM**. Actual program is located in so-called working part of memory. Desired winding program can be loaded to the working part of memory either from internal memory of the Winder, USB flash drive or a PC equipped by software GRAPHIC.



Proceeding by program selection:

- internal memory - see section 7, page 50
- USB flash drive - see section 10, page 62
- PC - see GRAPHIC manual

5.6 Start and stop of winding cycle (program)

Winding cycle is actuated by pressing START-button (4), or foot pedal.

There is a possibility to start program from each step. Required step is set up by the buttons

, or numeric keyboard.

STOP-button (5) interrupts the winding cycle. It is the priority button, what means, that the cycle interruption at incorrect time (while deceleration), may cause inaccurate stopping and positioning of the spindle.

Cycle interruption at the step WINDING allows almost all corrections and adjustments. Repeated cycle start by START-button or foot pedal activates step, where the program interruption has been done.

Step types SHIFT, JUMP and PAUSE do not allow any corrections or adjustments during interruption.

5.7 Foot pedal

Winding machine may be equipped by following types of foot pedals:


Double foot pedal controls START, BRAKE RELEASE

- left pedal releases the spindle brake
- right pedal works as parallel START-button

Double foot pedal controls SPEED, BRAKE RELEASE



- left pedal releases the spindle brake
- right foot pedal controls spindle speed depending on pressing level

Maximal speed, acceleration and deceleration ramp may be set up by PEDAL button.



Speed set up like this, is valid for assigned program and it is independent on speed programmed, in single program steps. Explain as: max.speed (ordinary lower) set up by START pedal may be different, then max.speed set up by START-button.

If we require the same max.pedal speed as speed, programmed in single program step, we need to press multifunction button PROGRAM SPEED.



Accel. / Decel. ramp for pedal

CODE	Accel.time (sec.)	Decel. time (sec.)
1	1	0,5
2	2	1
3	3	1,5
4	4	2
5	6	3
6	8	4
7	10	5
8	12	6

Max. pedal speed is controlled by values, programmed in single program steps, in this case.

Acceleration and deceleration ramp values are always taken from window PEDAL SETUP.

Winding cycle start continuity

This option is utilized during winding start. Wire application and winding of the first turns is done by pedal and then by pressing START-button (4) cycle continues.

5.9 WINDING CORRECTIONS

Program corrections and adjustments are allowed only in the state "STANDSTILL" or "Winding STOP". Keys are blocked in other states. When there is beep warning after the key pressing, the operation is illogical or inaccessible.

5.9.1 Spindle reference position setting

The spindle can be positioned in the range \pm a few degrees and exact position is kept for any amount of windings.

Reference (zero) spindle position is set up by follows:


- switch the brake-off by the switch (6)
- turn the spindle manually to the required position and return the switch (6) to the former position
- press RESET then ENTER


Note: When you switch the machine ON (by switch POWER or EMERGENCY STOP), RESET is running automatically and the spindle position is taken as reference position.

5.9.2. Wire guide relative position setting

This correction shifts zero coordinate of the wire guide (relative zero position). It allows you to correct the wire guide position to be in accordance with the bobbin or winding tool.

Default : 5 mm








Holding the buttons pressed (cca 0,5 s) moves the wire guide continuously.

5.9.3. Number of turns correction

We can change the number of turns counted actually.

Correction of decimal turn number e.g. XX.3 to XX.0 without adequate spindle turn, leads to the loss of reference position..






Multifunction RESET-button set to zero actual counter state.

5.9.4 Total counter


We can switch between TOTAL COUNTER and COUNTER. TOTAL COUNTER counts all spindle turns until it is set to zero by RESET, or is set differently by numeric keyboard.

Both counters are independent. By switching is only displayed one of it !



5.9.5. Wire guide correction


Correction allows you to correct the wire guide position while winding process.



Holding the buttons pressed (cca 0,5 s) moves the wire guide continuously.


5.9.6. Wire guide direction change

Correction allows you to change the direction of wire guide while winding.




5.9.7. Step abort

Correction allows you to abort actual running step.





Multifunction ABORT STEP button returns the STANDSTILL state.




5.9.8. Back winding

Correction allows you to wind back the required number of turns.




We can wind back required number of turns only by pedal. The number of turns is counted back and the wire guide moves in opposite direction.



Pressing of multifunction button "WINDING" ends back winding.

5.9.9. Deceleration ramp for the STOP-button

Deceleration ramp for the STOP button can be set. This ramp is whenever a bit faster (control by software) than programmed deceleration ramp.




CODE	TIME [s]
1	1,0
2	1,5
3	2,0
4	3,0
5	4,0
6	6,0
7	8,0
8	12,0


Presentated values are valid for max.speed.

6. PROGRAMMING


Entering the data:



Use the ENTER-button for execution entered value or for return from any function.

Programming is not possible in the step 00. By button  or numeric keyboard we need to choose any other step. When there is beep warning after the keep pressing, the operation is illogical or inaccessible.


Created program is saved to the working part of memory (program in this memories is designated as a ACTUAL PROGRAM). We can either overwrite (or modify) the already existing program, or open the new one.





6.1 Basis of programming

Winding program is logical sequence of a few(1-350) joined steps.



Joining to the next step is defined by the type of cycle.

If the type of cycle "END " is programmed to the specific step, it comes to this, that end of program and after pressing START- button, program is restarted and step 1 is running.


Max.step capacity for the one winding program is 350 !



6.2 Step choice

Only in the winding or viewable window we can choose the required step as follows:

a) directly by numeric keyboard

b) by buttons





6.3 Step parameters programming

6.3.1 Basic step types

Every step can be programmed as WINDING, SHIFT, JUMP or PAUSE.


Winding - is defined by following parameters: number of turns, speed and spindle direction, pitch, left and right reversal point


Shift - spindle is not turning and the wire guide is shifting to the programmed coordinate

Jump - spindle is not turning and the wire guide is shifting from its position to the left or right, in accordance with the programmed value

Pause - spindle and wire guide are idle and the pause duration depends on programmed time

6.3.2 Choice of step type




By pressing the button  and then by pressing the multifunction buttons we can choose the desired step type. Concurrently, we can enter the main parameter of the chosen step type, what means:

- number of turns for winding
- coordinate value for shift
- length for jump
- time for pause




6.3.3 Winding step

Number of turns




If " 0 " is programmed to the number of turns, this winding step turns the spindle to the zero reference position. Direction of the spindle speed is taken from the previous winding step !



Spindle speed



Spindle acceleration and deceleration







Entry of values 1 to 8 for acceleration and deceleration according to the enclosed table.






CODE	ACCEL. (s)	DECCEL. (s)
1	1,5	1,5
2	2,3	2,3
3	3	3
4	4,5	4,5
5	6	6
6	9	9
7	12	12
8	16	16

Spindle direction and protection shield







-  Protection shield programming
-  Spindle direction programming

Pitch





Left reversal point






Right reversal point




Switching OFF the wire guide shifting during programming

We can switch OFF the wire guide shifting by multifunction button SHIFT ON / OFF during programming.



Type of cycle

Set the type of cycle and choose, how to continue to the next step.



END



End of program

By pressing START-button, program is restarted and step 1 is running.

STOP



Cycle stop

After step finish, program stops and the next step is activated by START-button.

ContSLOW



Continual cycle with deceleration




After step finish, program starts the next step automatically, without pressing the START-button. Winding step decelerates to zero, at first.

ContFAST





Continual cycle without deceleration


After step finish, program starts the next step automatically, without pressing the START-button. Spindle deceleration is canceled. Only winding steps can be joined by this cycle.



Number of turns cancel and the wire guide direction after start



 Number of turns cancel after start

 Wire guide direction after start

Number of turns cancel.

CANCEL - previous counted number of turns is cancelled after START-UP the winding type of step


NOT

CANCEL - counted number of turns is not cancelled

Wire guide direction after start.





-right moving the wire guide after START -UP,if its position is between left and right reversal point




- the same, but left moving

6.3.4 Wire guide shift


Coordinate of shift






Speed of the shift

The speed of shift is set at 100 mm/sek automatically, while programming. If lower speed is required, we can change it as follows:.




Type of cycle




6.3.5 Wire guide jump




Length of jump



Direction of jump





Type of cycle



6.3.6 Pause

Time of pause





Step : 4 PROGRAMMING DELAY SHIFT
 Prog.: NEW

1200.0 WINDING

Range : 1 - 99990 [msec]
 Enter time of delay ! DELAY




ENTER

Step : 4 DELAY LAYER
 Prog.: NEW

Delay : 1200

Cycle :

Type of cycle



Step : 4 PROGRAMMING CYCLE END STOP
 Prog.: NEW

Enter type of cycle !

ContSLOW

ContFAST



ENTER

Step : 4 DELAY LAYER
 Prog.: NEW

Delay : 1200


Cycle :


6.4 Display and assignment of the layer

We can display the number of layer instead of program. Readout showed on display can be switched by multifunction button.



We can assign the layer number to every step, according to winding instruction. The same number of layer can be assigned to a few consecutive steps. While winding, the assignment is displayed as it is programmed.





6.5 Programming corrections


Following functions simplify programming or corrections.


6.5.1 Empty step insertion

Empty step can be insert anywhere inside the program and then can be completed with required parameters. Following steps are shifted in value "+1", automatically.




Position for step insertion is chosen by buttons







6.5.2 Step cancel

Each step in program can be canceled. Following steps are shifted in value "-1", automatically.



Step, which we wish to cancel is chosen by buttons






→ ENTER


6.5.3 Step copy

Each step, already programmed, can be copied to another step (previous or next).



Actual step is copied and inserted to the step, which is chosen by buttons


- +



→ ENTER

6.5.4 Global change


Function allows you to change one chosen parameter in all the following steps, which must be the same type. For example: if the actual step is winding, chosen parameter will be changed in all following winding steps. This is valid for all other step types (SHIFT,JUMP,PAUSE).



The pitch is changed in all other consecutive winding steps.

6.5.5 Coordinate offset

Correction provides offset all coordinates in program to the left or right about entered value.




All programmed coordinates / left,right reversal points and shifts/ are incremented about value 20,0 mm.

6.6 Special functions

6.6.1 Layer stop

This function activates winding step STOP, after each wound layer.




Until programmed number of turns is not reached, machine stops after each layer on the left or right reversal point.


If the assigned layer is displayed, this function will increment its value automatically, after each layer.






6.6.2 Automatic correction

Utilization of this function is mainly related to previous function LAYER STOP. It allows you to correct wire guide position after following start of the layer.



After the first layer is wound (e.g. from left to the right), press the wire guide correction button and correct the wire guide position. This corrected position is saved by pressing SAVE AS RIGHT CORRECTION button. Likewise, we insert and save the left correction after the second layer (from right to the left) is wound. For all the following layers in this step, all the corrections are done automatically, after start.






Maximal value for wire guide correction can not overreach ± 10 mm position diversion, after the layer is wound. Higher values are not accepted !

6.6.3 Automatic switch to manual regime

Function provides automatically machine switch to manual regime, after the layer or whole winding step is completed.


We can wind, just by foot pedal in manual regime. Also, the value of the pitch is taken from the actual step. The wire guide direction is controlled by multifunction button WIRE GUIDE DIRECTION. The number of turns, that is wound in this regime is not defined.





Manual regime switch OFF is done by pressing MANUAL button.

6.6.4 Trapezoidal winding

Function provides shifting of reversal points after each layer automatically.






Switch function off

Available form of trapezoidal windings :


	left trapezoid : OFF	right trapezoid : / X,X
	left trapezoid : OFF	right trapezoid : \ X,X
	left trapezoid : \ X,X	right trapezoid : OFF
	left trapezoid : / X,X	right trapezoid : OFF
	left trapezoid : \ X,X	right trapezoid : /X,X
	left trapezoid : / X,X	right trapezoid : \ X,X
	left trapezoid : \ X,X	right trapezoid : \ X,X
	left trapezoid : / X,X	right trapezoid : / X,X

6.7 Auxiliary inputs and outputs


Machine provides an opportunity to program and control up to 4 auxiliary digital outputs and 4 digital inputs in each step. Digital inputs and outputs are galvanise isolated. Relay is applied in standard equipment.



6.7.1 View window for inputs and outputs




6.7.2 Digital inputs programming



Each digital input can be programmed as:


- NA** - input is inactive
- I** - winding cycle interruption is done, if input is high (+ 12 V)
- S** - winding cycle start is done, if input is high (+12 V)
- SB** - start is blocked, while duration of high (+ 12V)





6.7.3 Digital outputs programming




3 following parameters can be programmed in digital outputs 1 - 4:

- level of output, after step start - up (L - relay on, H - relay off)
- level of output, after step finish - up (L - relay on, H - relay off)
- delay of output action






Delay




ENTER





6.8. Program name

Created winding program should be named for quick and easy orientation. The name can consist of max.24 characters in accordance with Character scheme. If winding programs are stored to USB flash drive as well, is highly recommended to use format **8.3** (1 to 8 characters, optionally followed by a period "." then extension up to 3 characters.) For example "ern-test.tpc"


Long file names for USB flash drive are not supported !








7. Program saving and opening


Actual program is placed in working part of memory. This program can be saved to an optional block or other saved program can be opened.




7.1 Program opening



Listing by button or









7.2 Program saving




Capacity of the internal memory is 11500 steps divided to 160 blocks. Max. step capacity is limited as follows

- Blocks 1 - 10 : max.capacity up to 350 steps
- Blocks 11 - 20 : max.capacity up to 100 steps
- Blocks 21 - 160 : max.capacity up to 50 steps






Select block for saving




Correct program name if required




8. MENU

Displays and allows to change some machine basic setting.




Step : 2	MACHINEsetup	NEXT (1)
Prog.: 12	MENU	
Model : ERN - 150		PROGRAM LOCK
Number: 3		
Version : 055.816.442		USB Disc
Licence : 1115		
Gear : 300 [rpm]		
Max. width : 800.0 [mm]		
Programming : UNLOCK		

 Program locking

 USB flash drive


Step : 2	MACHINEsetup	NEXT (2)
Prog.: 12	MENU	
Model : ERN - 150		MODEL
Number: 3		
Version : 055.816.442		LANGUAGE
Licence : 1115		
Gear : 300 [rpm]		
Max. width : 800.0 [mm]		
Programming : UNLOCK		

 Machine model choice

 Display language


Step : 2	MACHINEsetup	NEXT (3)
Prog.: 12	MENU	
Model : ERN - 150		JOYST.UP
Number: 3		MODE 1
Version : 055.816.442		
Licence : 1115		
Gear : 300 [rpm]		
Max. width : 800.0 [mm]		JOYST.DOWN
Programming : UNLOCK		MODE1


 Joystick action UP

 Joystick action DOWN

Step : 2	MACHINEsetup	NEXT (4)
Prog.: 12	MENU	
Model : ERN - 150		DELETE PROGRAM
Number: 3		
Version : 055.816.442		
Licence : 1115		
Gear : 300 [rpm]		
Max. width : 800.0 [mm]		CHANGE PIN CODE
Programming : UNLOCK		

 Program delete


 Access code setting



Display program or layer




Error messages



Winder number



Accept file name



Factory settings


8.1 Program locking

Programming can be locked or unlocked by entering MASTER or PIN code. Corrections which are performed during winding process (wire guide correction, back winding, abort step etc.) are not blocked.

8.2 USB flash drive


Entry to USB flash drive directory. If USB flash drive is not connected, the button is inactive.

8.3 Machine model choice




8.4 Display language

Allows you to choose display language.




8.5 Joystick action

If the machine is equipped with a four-way joystick, the action of its UP and DOWN position can be programmed. Left and right position is fixed for wire guide correction.



8.6 Program (block) delete

Working part of memory and appropriate block can be deleted.





8.7 Access PIN code setting

Available codes for user :

- MASTER code - allows you to change all settings in menu. This code is fixed by producer and is referred to guarantee certificate.
- PIN code - lock and unlock programming. This code can be set by user in range 0 - 999999
Default : "0"


8.8 Error messages

Digital control by CAN- bus provides to store and display eventual errors of Servo Drive. Displayed errors are dedicated for service.



8.9 Winder number

Winder number can be set for easy network identification.




8.10 Accept file name

Winding programs, stored as files on USB flash drive or PC, can be named in different, for example short form, as the previous.


COPY NAME
YES

- file name is accepted and displayed as a name of coil.



COPY NAME
NO

- file name is not displayed as a name of coil.



9. ERROR report

Mistakes in program are displayed by writing ERROR messages:

ERROR Microswitch

Mechanical displace of the wire guide. It appears in case, that the lateral power on the wire guide overcomes the torque of the step motor.

Next procedure: press RESET

ERROR Spindle speed versus pitch

Pitch or spindle speed is too high (exceed the max.wire guide speed 75 mm/sek)

Next procedure: press ENTER and correct either spindle speed or pitch

ERROR Wire guide position out of range

Winding width is out of range.

Next procedure: press ENTER and correct either relative position or reversal points

ERROR Program is not logic

Program is not logic in the case type of cycle ContFAST, next step can not be the shift, jump or winding with the opposite speed direction.

10.USB host port

The controller is equipped with USB host port. This port is designed only for a USB flash drive. Do not connect any other equipments (mouse, keyboard, etc.) to this port!



The suitable USB flash drive is delivered with each new machine. Mostly of another USB flash drives (KINGTON,PQI,SANflash drive) can be used. We recommend to test optimal model-especially as for writing speed.

There are limitations to the type of flash drive which can be used. All flash drives must have a sector size of 512bytes. Various cluster sizes have been tested up to 32kB. Formatting FAT 16 or FAT 32.

Key features


- provides reading from or writing to a USB flash drive
- tree directory for a quick program searching
- storage of unlimited winding programs
- easy transfer winding programs to or from a PC.
 - No other communication program needed
 - and no problem with cables and correct port setting
- simply and easy way for machine upgrade.
 - Files for upgrade can be sent by e-mail
- back-up of all winding programs in machine memory

If a flash drive is connected to USB port, then the root directory of the flash drive is displayed






Press to return to the winding window






Press **MENU** → **USB** to return to the root directory





You can disconnect the flash drive when no file is read or written.

Warning ! : If a flash drive is removed during a write operation then data corruption is likely


10.1 Display help




Press to display help



Press to return to the root directory



10.2 Tree type structure



change directory

choose directory or file

Pres or to change list of directory

Max. number of displayed files or subdirectories in one directory is 100






Filename format consists of 1 to 8 characters, optionally followed by a period (".") then an extension of up to 3 characters. (8.3) For example " ern-test.tpc "





Except letters and numbers one of the following characters can be used : - _ & Space is not allowed !

IMPORTANT : Long file names are not supported .


Note : Uppercase - name of directory
Lowercase - name of file

10.3 Read from flash drive












10.4 Save actual program to flash drive.



actual program






choose directory or file












You can change or modify the name and extension .






10.5 Create new directory







IMPORTANT : Long file names are not supported .




10.6 Delete file or directory



10.7 Rename file or directory







2x





ENTER

10.8 Save marked programs to USB flash drive








choose list









choose file to mark



Required file mark by using key "C"








10.9 Save programs 1- 80 (81-160) to USB flash drive



The same procedure for programs 81-160 by key 6

10.10 Load program from USB flash drive



Note : Files will be saved in the machine's memory according to the suffix order (001-160).

Files not marked 001-160 on the flash drive will not be transferred.




10.11 Firmware Upgrades

Upgrade files sent by E-mail provide upgrading the firmware if required.


There are two type of Upgrade files :



- tpccrxxx.tpc - Upgrade for the control board
 - tpcdpxxx.tpc - Upgrade for the display and key board
- where : xxx is version number (for example tpccr442.tpc)

Important : Consult each Upgrade and especially suitable combination of versions with manufacturer.




Control board upgrade





Enter your MASTER CODE




ENTER



Wait for ENTER





Note : Upgrade tpcrxxx.tpc takes approx.one minute




check version


Display board upgrade




Enter your MASTER CODE




Wait for switch OFF/ ON



Between switch OFF and ON please wait a few seconds.



Note :Upgrade tpcdpxxx.tpc takes approx. two minutes



check version

11. GEAR CHANGE

11.1 GEAR CHANGE ERN 100

Timing belt drive is under the cover (15).
The machine is delivered with the default "300" gear.

Changing to the gear "600":

- switch off the machine and unplug it
- remove the cover (15), attached by 3 screws
- loosen 4 screws (17) and remove the timing belt

- remove the "300" timing gear and replace it with the "600" gear.
- use the shorter timing belt, put on, tension and attach it with the screws (17)

After each gear change is necessary to rewrite the new gear to the controller.

11.2 GEAR CHANGE ERN 150

Timing belt drive is under the cover (15).
The machine is delivered with the default "150" gear.

Changing to the gear "300":

- switch off the machine and unplug it
- remove the cover (15), attached by 3 screws
- loosen 4 screws (17)

- remove the "300" timing gear and replace it with the "150" gear.
- use the shorter timing belt, put on, tension and attach it with the screws (17)

After each gear change is necessary to rewrite the new gear to the controller.

11.3 GEAR CHANGE ERN 200

Timing belt drive is under the cover (15).
The machine is delivered with the default "150" gear.

Changing to the gear "75":

- switch off the machine and unplug it
- remove the cover (15), attached by 3 screws
- loosen 4 screws (17)


- remove the "150" timing gear and replace it with the "75" gear.
- tense timing belt, and attach it with the screws (17)

After each gear change is necessary to rewrite the new gear to the controller.

12. Serial interface RS 232

The machine is equipped with the optically isolated serial interface RS 232 for communication with PC. Connecting cable and software, offered by producer as optional accessories, allows to create and file winding program in PC.

Connector scheme



Pin	Signal
1	
2	S in
3	S out
4	
5	GND
6	
7	
8	
9	12V DC/100mA

13. PACKAGE CONTENTS

ERN 100,150

Documents delivered with the machine:

- 1 pc certificate of quality and completeness
- 1 pc user's guide
- 1 pc AC servo drive user's guide
- 1 pc APC Smart-UPS user's guide

Supplied Accessories:

- 2 pcs fuse T 315 mA/250 V
- 2 pcs fuse T 1,25 A/250 V
- 1 pc microswitch WN 559 00
- 1 pc timing belt 5MR - 600 -25 (ERN 100)
- 1 pc timing belt 5MR - 700 -25 (ERN 150)
- 1 pc timing gear 60 5M 25 - 6W
- 3 pcs allen key

ERN 200

Documents delivered with the machine:

- 1 pc certificate of quality and completeness
- 1 pc user's guide
- 1 pc AC servo drive user's guide
- 1 pc APC Smart-UPS user's guide

Supplied Accessories:

- 2 pcs fuse T 630 mA/250 V
- 2 pcs fuse T 1,25 A/250 V
- 1 pc microswitch WN 559 00
- 1 pc timing gear 36 teeth
- 3 pcs allen key

14. FUSE CHANGE

Change the wrong fuses at the power switch OFF and the main power plug disconnected. The fuses are on the back panel of the drive box. Be sure to use only the types of fuses specified by the producer.

15. MAINTENANCE

As the machine contains a minimum number of mechanical gears, the maintenance is simple. To ensure trouble-free work, following operations are recommended:

- clean regularly the winding space of dust, dirt and wire ends
- check tension of the timing belt
- the ball bearings have permanent grease filling, no lubrication is needed

16. WARRANTY PERIOD AND SERVICE

Warranty period is 24 months from the date of delivery.
Warranty and after warranty repairs are provided by the producer.