





SPARE PARTS ERN 22T



- | | |
|---|----------------|
| 7. PC | Uniq PC150 |
| 8. Joystick | APEM No 100212 |
| 24. Brake switch | TA 048 75 |
| 25. Emergency stop | TA 048 71 |
| 26. Stand-by switch | TA 048 73 |
| 27. Stop - button | TA 026 42 |
| 28. Start - button | TA 026 41 |
| 29. Protection shield | TF 001 11 |
| 29a. Shield | TA 003 65 |
| 29b. Spring | TA 009 62 |
| 29c. Magnetic switch | TA 026 36 |
| 30. Spindle collet chuck $\varnothing$ 10mm | TA 004 40 |
| 31. Nut | TA 004 78 |
| | TA 004 38 |



SPARE PARTS ERN 22T




- 9. Time relay
- 10. AC servo amplifier
- 11. Servomotor
- 12. Spindle
- 12a. Ball bearing
- 13. Brake
- 14. Wire guide unit
- 14a. Step motor
- 14b. Timing belt
- 14c. Microswitch
- 14d. Ball bearing of wagon
- 14e. Ball bearing of spindle
- 15. Connector for foot- pedal
- 17. Mains transformer
- 19. Fuse case
- 20. Stepper motor driver
- 20a. Connector
- 22. Connector
- 23. Connector
- 34. Connector
- 35. Relay

FINDER 1CO-SPDT16A-250V
 SERVOSTAR 306
 TGT3 -0250 - 45 - 320/TOPS1
 TA 020 52
 6003 2ZR P6C6
 Lenze 24V11,5W d=17
 TF 000 08
 Vexta PK268- 02A
 138 teeth/12 mm
 WN 559 00
 625 2ZR P6
 6001 AZR
 TA 026 44
 ST15/02
 SI-HA 125000
 TK 000 30
 BLA4, BLA6, BLA8, BLA14,
 SLA4, SLA6, SLA8, SLA14
 TA 060 41
 TA 021 95
 TA 060 40
 RSI-20-20-A230




SPARE PARTS ERN 22T


Gear
3 000 rpm



Gear
12 000 rpm



Gear
6 000 rpm




- 36. Timing gear TA 020 90 (64 teeth)
- 37. Timing gear TA 020 88 (20 teeth)
- 38. Timing gear TA 020 89 (32 teeth)
- 39. Timing gear TA 020 87 (25 teeth)
- 40. Timing belt ZR-210XL (105 teeth/9.5 mm)
- 41. Timing belt ZR-160XL (80 teeth/9.5 mm)



SPARE PARTS ERN 22T

Controller box



- 1. PCB
- 2. Backplane
- 3. Mains filter

TK 000 - 80 - 003
TK 000 73 - 00
ETI 39.19.160