





SPARE PARTS ERN 32 SG



- | | |
|--|-----------|
| 24. Brake switch | TA 048 75 |
| 25. Emergency stop | TA 048 71 |
| 26. Stand - by switch | TA 048 73 |
| 27. Stop - button | TA 026 42 |
| 28. Start - button | TA 026 41 |
| 29. Protection shield | TF 000 95 |
| 29a. Shield | TA 021 42 |
| 29b. Spring | No 12 |
| 29c. Magnetic switch | TA 048 77 |
| 30. Spindle collet chuck \varnothing 12 mm | TA 013 23 |
| Spindle collet chuck \varnothing 10 mm | TA 007 31 |
| 31. Nut | TA 007 37 |




SPARE PARTS ERN 32 SG



- | | |
|--|-----------|
| 24. Brake switch | TA 048 75 |
| 25. Emergency stop | TA 048 71 |
| 26. Stand-by switch | TA 048 73 |
| 27. Stop - button | TA 026 42 |
| 28. Start - button | TA 026 41 |
| 29. Protection shield | TF 001 12 |
| 29a. Shield | TA 023 08 |
| 29b. Spring | TA 009 62 |
| 29c. Magnetic switch | TA 026 36 |
| 30. Spindle collet chuck \varnothing 10 mm | TA 013 23 |
| Spindle collet chuck \varnothing 12 mm | TA 007 31 |
| 31. Nut | TA 007 37 |



SPARE PARTS ERN 32 SG




- | | |
|--------------------------------|---|
| 10. AC servo amplifier | SERVOSTAR 346 |
| 11. Servomotor | TGH4 -0780 - 25 - 560/T1PS1X |
| 12. Spindle | TA 008 21 |
| 12a. Ball bearing | S6204 CTA ABC7 DUL 85N |
| 12b. Ball bearing | 6204 P66 |
| 13. Brake | Lenze 24V21W d=20H7 |
| 14. Wire guide unit | TF 000 71 |
| 14a. Step motor | Vexta PK2913-E4.0b |
| 14b. Timing belt | 198 teeth/20mm |
| 14c. Textile band | 2x20x1000 |
| 14d. Microswitch | WN 559 00 |
| 14e. Ball bearing | 6002 AZR |
| 14f. Ball bearing | 6001 AZR |
| 15. Connector for foot - pedal | TA 026 44 |
| 17. Mains transformer | ST 01/03 |
| 19. Fuse case | SI-HA 125000 |
| 20. Stepper motor driver | TK 000 30 |
| 20a. Connector | BLA4, BLA6, BLA8, BLA14,
SLA4, SLA6, SLA8, SLA14 |
| 22. Connector | TA 022 95 |
| 23. Connector | TA 021 95 |
| 32. Relay | RSI-25-40-A230 |
| 33. A. C. circuit breaker | LPN-6C-3 |
| 34. Connector | TA 048 67 |




SPARE PARTS ERN 32 SG

Gear
500 rpm




37 42 36

Gear
4 000 rpm



39 41 37

Gear
1 000 rpm




37 41 38

- 36. Timing gear TA 045 04 / 100 teeth /
- 37. Timing gear TA 045 02 / 20 teeth /
- 38. Timing gear TA 045 01 / 50 teeth /
- 39. Timing gear TA 045 03 / 32 teeth /
- 41. Timing belt 5MR-500-25 / 100 teeth./25mm /
- 42. Timing belt 5MR-650-25/ 130 teeth./25mm /



SPARE PARTS ERN 32 SG



- 1. PCB 1.
- 2. PCB with keyboard
- 3. Backplane
- 3a. Mains transformer
- 3b. Fuse for bluetooth adapter
- 4. Display
- 6. Mains filter
- 7. Connector cable - display
- 8. Connector cable -RS 232

- TK 000 50 - 02
- TK 000 60 - 01
- TK 000 51 -04
- TRZ 007/ST 39 - 01
- 160mA/250V
- PLANAR EL.240.128.45
- ETI 39.19.160
- TA 032 00
- TA 032 01